

**2001
LINCOLN
LS SEDAN**



Year: 2001 Make: Lincoln Model: LS

IN-DASH APPLICATION:

Dash Type: DIN and Half
Kit: LN1328
Harness: FDK9

FRONT SPEAKERS:

Front Door: 6x8" mounted to factory adapter

When installing an aftermarket 5 ¼" or 6 ½" speakers, a speaker adapter is needed. We recommend the Scosche SA69 speaker adapter.

REAR SPEAKERS:

Rear Door: 6x8" mounted to factory adapter

When installing an aftermarket 5 ¼" or 6 ½" speakers, a speaker adapter is needed. We recommend the Scosche SA69 speaker adapter.

WIRE COLOR CODES:

+12V CONSTANT	=	ORANGE/BLACK
+12V Accessory Switched	=	Yellow/Green
-12V Chassis Ground	=	Black
+12V Illumination	=	
LF+	=	White/Black
LF-	=	Grey/Black
RF+	=	White/Red
RF-	=	Grey/Red
LR+	=	White/Purple
LR-	=	Grey/White
RR+	=	White
RR-	=	Grey

2001 Lincoln LS Sedan

PRELIMINARY: Disconnect the negative battery cable.

ANTENNA: Factory Antenna is integrated into the rear window.

RADIO REMOVAL AND IN-DASH INSTALLATION:

Note: The factory radio provision is for a DIN and Half sized radio. No kit available yet.

1. Unsnap rear AC vents, Pull away.
2. Pull up on center console, disconnect and remove.
3. Using panel removal tool pry away ashtray trim bezel and remove.
4. Using 9/32 remove (2) bolts from ashtray assembly, disconnect and remove.
5. Using panel removal tool, pry out upper AC vents, Disconnect and remove
6. Using 8mm removal (4) bolts securing radio assembly, Disconnect and remove.



FRONT DOOR SPEAKER INSTALLATION:

Note: The factory speaker provision is for a 6" x 8" Speaker is riveted into door.

1. Snap off door opener bezel from front to back and remove.
2. Pry out window control panel at front then lift out, Disconnect and pull away.
3. Using small pick, pry out screw cover in door cup and extract (1) Philips head screw.
4. Extract (3) Philips head screws from bottom of door panel.
5. Extract (1) Philips head screw from rear of door panel.
6. Using panel removal tool pry plastic snaps loose around entire door perimeter, Disconnect and remove panel.
7. Extract (4) 5mm screws securing speaker, disconnect and remove.



REAR DOOR SPEAKER INSTALLATION:

Note: The factory speaker provision is for a 6" x 8" 4-Hole Standard mounted directly to metal.

1. Snap off door opener bezel from front to rear and remove.
2. Pry out window control module at front then lift out, Disconnect and remove.
3. Using small pick, pry out screw cover in door up and extract (1) Philips head screw.
4. Extract (3) Philips head screw from bottom of door panel.
5. Extract (1) Philips head screw from rear of door panel.
6. Using panel removal tool pry plastic snaps in door perimeter loose, disconnect and remove panel.
7. Extract (4) 5mm screws securing speaker, disconnect and remove.

